

1997-02 Triumph Speed Triple Frame Sliders

Installation Instructions for item 16B (black) or 16W (white)

Parts List:

Two 1.75 inch (44.5mm) diameter delrin plastic sliders.
Two M12 Nylock nuts.
Four M12 washers.
One left billet aluminum bushing (shorter).
One left M12 x 80mm (shorter) bolt.
One right billet aluminum bushing (longer).
One right M12 x 100mm (longer) bolt.

Tool Requirements:

Torque wrench; T55 Torx Socket; metric wrench and socket set.

Slider Install:

1. Remove original left side mounting bolt using T55 Torx socket.



SkykingProducts.com

3934 Santa Nella Place, San Diego, CA 92130 USA
Phone: 858-337-5267 E-mail: info@skykingproducts.com



2. Install shorter slider with aluminum bushing using the shorter M12 bolt/nut and torque (45 to 62 pounds).



3. Repeat steps one and two above using the longer aluminum bushing and longer M12 bolt for the right side.