

# SKYKING Skykingproducts.com

15701 Broad Oaks Road  
El Cajon, CA 92021

858 / 337-5267  
john@skykingproducts.com

## **Triumph: License Plate & Turn Indicator Relocation ASSY**

**Application: Triumph Daytona 955i (all); Speed Triple (97-04); ST (98-04) and RS(all); Speed 4 (all) and TT600 (all)**

Item: 023

Rest assured that you are purchasing the highest quality product available made by experienced craftsmen in the USA. This durable under tail section license plate and turn indicator assemblies provide a clean mounting provision after the rear under tray has been modified. These are made rust proof super strong .1875 inch black plastic for years of service. It is designed to fit the standard 4" x 7" license plate. The turn indicator brackets are adjustable to accommodate the different length turn indicators, which is another Skykingproducts.com idea. Easily removed for track days. Designed to compliment the stunning good looks of your Triumph rear section.

#### Parts contents:

One License plate holder.

One left indicator bracket.

One right indicator bracket.

Four 6mm indicator bracket bolts.

Four 6mm indicator bracket nylock nuts.

#### Installation Data:

**Special Equipment:** Dremel tool with a cut off attachment and or hacksaw blade. Drill and drill bit.

**Rear under tray Modifications:** Cut under tail section area.

#### Precautions:

1. You may wish to apply adhesive tape on the under tail sections where you will be making the cut and mark your cut. This way you have something to follow.
2. Let the cutting tool do the cutting and do not allow the plastic to over heat. If you rush the cutting process the plastic under tray will melt and fuse back together at the cut.

#### License Plate & Turn Indicator install:

1. Remove tail section body work.
2. Cut off the under tray portion that currently holds the license plate. Take your time measure twice before making the cut. Finish the cutting surface by using sandpaper.
3. Position license plate ASSY and drill two or four ¼ inch holes in the under tray.
4. Install two or four customer supplied mounting bolts. You can use the ones from the metal OEM bracket that was removed. Note: We recommend the use of a Nylock nut.
5. Install customers supplied turn indicators and adjust turn indicator bracket width by sliding the left and right brackets as required. You can also rotate the brackets to get the turn indicators next to the license plate. Drill one or two holes for turn indicator wiring access.
6. Install license plate using customer supplied mounting bolts.

Note: Single sided swing arm motorcycles only. Install original license plate light on the under tray directly above the license plate ASSY.